+ AUTODOC CLUB

How to change spark plugs on **Audi A4 B7** – replacement guide







VIDEO TUTORIAL



important!

This replacement procedure can be used for:

AUDI TT Coupe (8J3) 2.0 TFSI, AUDI TT Coupe (8J3) 2.0 TFSI quattro, AUDI TT Roadster (8J9) 2.0 TFSI, AUDI TT Roadster (8J9) 2.0 TFSI quattro, AUDI A6 Saloon (4G2, 4GC, C7) 2.0 TFSI, AUDI Q5 (8RB) 2.0 TFSI hybrid quattro, AUDI A6 Avant (4G5, 4GD, C7) 2.0 TFSI, AUDI Q3 (8UB, 8UG) 2.0 TFSI quattro, AUDI A5 Convertible (8F7) 1.8 TFSI, AUDI A6 Saloon (4G2, 4GC, C7) 2.0 TFSI hybrid, AUDI A8 (4H2, 4H8, 4HC, 4HL) 2.0 TFSI hybrid, AUDI A3 Sportback (8PA) 2.0 TFSI, AUDI A3 Sportback (8PA) 2.0 TFSI quattro, AUDI A3 Hatchback (8P1) 2.0 TFSI quattro, (+ 45)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-10







REPLACEMENT: SPARK PLUGS – AUDI A4 B7. LIST OF THE TOOLS YOU'LL NEED:



- Electronic spray
- High-temperature anti-seize lubricant
- Torque wrench
- Torx bit T20
- Spark plug socket # 16

- Ratchet wrench
- Flat Screwdriver
- Clip removal tool
- Crow bar
- Fender cover

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-10







Replacement: spark plugs – Audi A4 B7. AUTODOC experts recommend:

- The replacement procedure is the same for all spark plugs.
- All work should be done with the engine stopped.

REPLACEMENT: SPARK PLUGS – AUDI A4 B7. RECOMMENDED SEQUENCE OF STEPS:

1

Open the bonnet.



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



Unscrew the fasteners of the ignition coil harness retainer. Use Torx T20. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 3-10







4 Unplug the connectors from the ignition coils. Use a flat screwdriver.



Take out the ignition coil from the spark plug well. Use a clip removal tool. Use a crowbar.



Replacement: spark plugs - Audi A4 B7. Tip:

- Remember the sequence of steps for ignition coil demounting.
- 6 Clean dirt, dust and debris from inside the spark plug wells.



Unscrew the spark plugs. Use the spark plug socket #16. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 4-10







Take out the spark plugs. Use the spark plug socket #16.




Apply a thin layer of a special high temperature anti-seize lubricant to the threads of the new spark plugs.



Install the new spark plugs into their mounting seats. Use the spark plug socket #16.



Screw new spark plugs and tighten them. Use the spark plug socket #16. Use a torque wrench. Tighten it to 27 nm torque.



CLUB.AUTODOC.CO.UK 5-10







Replacement: spark plugs – Audi A4 B7. AUTODOC experts recommend:

- Don't tighten the plugs with excessive force. Exceeding tightening torque can damage the thread connection.
- Be careful when working with a spark plug wrench. Its skewing can cause damage to the threaded connection.





AUTODOC recommends:

- Replacement: spark plugs Audi A4 B7. Follow the installation steps.
- Treat the ignition coil connector with electronic spray. The spray will protect the electrical contacts from corrosion, oxidation, and will reduce the contact resistance.



CLUB.AUTODOC.CO.UK 6-10







Plug in the connectors of the ignition coils.



Screw in the fasteners of the ignition coil harness retainer. Use Torx T20. Use a ratchet wrench.



Remove the fender protection cover.



17 Close the hood.

18



Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

CLUB.AUTODOC.CO.UK 7-10











Shut off the engine.



VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 8-10





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR AUDI

SPARK PLUGS: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 9-10







CHOOSE CAR PARTS FOR AUDI A4 B7

SPARK PLUGS FOR AUDI: BUY NOW

SPARK PLUGS FOR AUDI A4 B7: THE BEST DEALS & OFFERS

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.

CLUB.AUTODOC.CO.UK 10-10